




Turn on the computer, then the LightDeck Mini Analyzer. Start the LightDeck-T software by double clicking the LightDeck-T icon on the desktop.

1) Click RUN TEST




- Choose a test.
- Fill in appropriate fields.
- Click ACCEPT to load inputs.

2) Remove pouch contents



- Remove cartridge and reagent tube from the pouch.
- Discard the dessicant.
- **Do not touch the clear plastic on the bottom of the cartridge.**

3) Add 100 µL sample



- Attach tip to supplied fixed volume pipette. Dispense 100 µL of sample into the reagent tube.
- Mix by pipetting up and down 10 times or until the detection reagent is completely dissolved

4) Add 100 µL sample



- Dispense 100 µL sample/reagent mixture into the cartridge.

5) Click READY



Click READY to open the door. The door stays open for 30 seconds.


6) Insert cartridge



The analyzer reads the bar code, populates the rest of the Sample Information and runs the test.

Result screen

- Processing takes 10 minutes.



- Click DONE to release cartridge.
- Click EXPORT to create a PDF report.

